

## Elftmann Tactical Anti-Walk/Anti-Rotate Trigger Pin Set





Line up flat end of pins with "D" shaped holes on back plate Then place master link over plate



Place flat blade screwdriver in slot



Push Master link into place



